



Use Instructions:

Thank you for your recent purchase of your new demo bench. The Tech Trainer/Parent Educator demo bench is for educational purposes only and is designed to help demonstrate the proper use and installation of car seats, booster seats and seat belts.

Follow these simple instructions to learn how to safely transport and use your new teaching tool.

Moving the demo bench:

- Unlock all four wheels by turning the metal plate to the unlock position.
- Raise the seat back to its full upright and locked position.
- Stand behind the seat back and place both hands on the top edge of the seat, near the head restraint.
- Buckle and secure the lap belt to avoid a trip hazard. Never allow the latch plate and/or webbing to drag on the ground. This will cause damage to the belt and poses a trip hazard.
- Slowly push the demo bench forward. Do not roll over uneven or rough surfaces. Doing so may damage the casters.
- Never pull the seat. Doing so may result in the demo bench tipping over and causing bodily injury and/or damage to the demo seat or other property.
- Do not leave unattended on uneven or sloped surfaces.
- **NEVER allow anyone to sit on, stand on or otherwise lean on the seat or any components while it is being moved. This can result in significant injury and damage to your demo bench which will void the warranty.**

Transporting, loading, and unloading the demo bench

Loading

- Lock the wheels.
- If equipped, fold your head restraints down by pulling the strap on the side of the seat, just below the head restraint.
- Gently lower the seat back by pulling up on the lever on the side of the demo seat. Avoid all pinch points.
- With a partner, **always** use proper team lifting technique to lift your demo bench, Stand on either side of the folded demo seat and lift from the bottom of the platform. NEVER attempt to load or unload the demo bench alone. Doing so may cause injury to you and/or your vehicle.
- Take care not to bump into the retractors. Doing so may cause the retractor to malfunction.
- Carefully set the folded demo seat into the cargo area of the vehicle. Properly secure the demo seat to avoid the risk of injury to you or your passengers.

Unloading

- With a partner, **always** use proper team lifting technique to lift your demo bench, Stand on either side of the folded demo seat and lift from the bottom of the platform. NEVER attempt to load or unload the demo bench alone. Doing so may cause injury to you and/or your vehicle.
- Take care not to bump into the retractors. Doing so may cause the retractor to malfunction.
- Carefully set the folded demo seat on a level, smooth surface.
- While standing in front of the seat, place your knee or hand on the seat and raise the seat back to its full upright and locked position.
- Unlock all four wheels by turning the metal plate to the unlock position.

Note: CPS Resources, LLC. Is not responsible for any damage to the vehicle or injury to any passengers in the vehicle.



CPS Resources, LLC

Use in the classroom:

A variety of seat belt systems and LATCH are available to demonstrate the proper use and installation of car seats, booster seats and seat belts. Follow these simple steps to ensure your demo seat functions properly.

- Always ensure all four wheels are in the locked position by turning the metal locking mechanism into the locked position. Do not leave unattended on uneven or sloped surfaces.
- Raise the seat back to its full upright and locked position avoiding all pinch points.
- Do not exceed 200lbs. weight limit on the demo bench.
- Do not allow multiple people to sit on the demo bench at one time.
- Avoid excessive force on any part of the demo bench. Doing so may cause damage and will void the warranty.
- NEVER allow anyone to sit on the seat while it is being moved. This can result in serious injury and damage to your demo bench which will void the warranty.

Latchplates

Each latchplate will lock into the buckle on the side of the seat. If you purchased the Tech Trainer, slide the unused latchplates on the shoulder belt out of the way to demonstrate how to properly install a car seat or booster seat. The seat belt contains the following latchplates:

- Sliding
- Dynamic/cinching
- Locking

LATCH

The lower anchors and top tether are used to demonstrate the proper use of the LATCH system. The top tether can be routed under or over the head restraint.

Retractors

Each demo seat comes equipped with a three-point belt system with a switchable retractor and a manually adjustable lap belt. The Tech Trainer model also comes equipped with an ELR lap belt.